

INSTRUCTIONS

PUTTING YOUR LUGGAGE INSIDE THE LOCKER:

1. Before you put your luggage inside the locker, check for a green LED on the locker's control panel. A green LED means the locker is empty and ready to use. You should also check for a key in the lock.
2. Put your luggage inside the locker and lock the door. Check if any element of the luggage is not caught by the door which could result in door jamming and problems opening it.
3. Make the luggage storage payment for the first 24 hours according to the price list.

The amount for payment is also displayed on the locker's LED panel.

PAYMENT FOR THE LOCKER CAN BE MADE BY MEANS OF:

- a) Cash - inserting the right coins: PLN 1, 2, 5 inside the slit on the locker's panel.
- b) Coins: PLN 1, 2, 5 and a contactless card. If during payment you realize that you have not got a sufficient amount of coins, you can pay the remaining balance using a payment card as indicated in c) below.
- c) Contactless card via a terminal on the locker's door.

Use the keypad to select the number of the locker you want to pay for. Press # to confirm.

The LED display will show the amount to be paid for the locker. Press # to confirm.

Next, move the contactless card close to the terminal - when a request for using the card is displayed.

4. Turn the key left until it stops to lock the locker.
5. Remove the key from the lock and take it with you.

TAKING YOUR LUGGAGE OUT:

1. Check the LED display for any additional payment to be made for exceeding the basic term of storing the luggage.

If there is no information about additional payment, proceed as indicated in 3. PUTTING YOUR LUGGAGE INSIDE THE LOCKER.

2. Turn the key right until it stops to unlock the locker.
3. Take your luggage out.

NOTE:

- * Every unlocking of the locker after 3 minutes from the locking will end the basic 24-hour term of storing the luggage and requires a new payment.
- * If the basic 24-hour term of storing the luggage is exceeded, you should make additional payment for service as indicated on the locker's panel.
- * The maximum time of storing the luggage in the locker is 72 hours. If this time is exceeded, the luggage will be removed to a storage room.
- * In case of any problems, please contact our service.

SERVICE PHONE NUMBER

THANK YOU FOR USING OUR LUGGAGE LOCKERS

PERSONAL DATA PROTECTION:

In order to pay with a payment card, the user of the Locker agrees to provide his/her personal data necessary to process the payment. The controller of such data will be e-Płatności S.A.

The payment will not be possible if this consent is not given.

Personal data will be processed only for the purposes of payment processing and for other purposes indicated by the payment operator, which is beyond the control of Euro Inwest – Bis Sp. z o. o.